TECHNICAL DATA SHEET

en

Name of product:

FAXE Active Care 0280 07300 - 07301

Type of product: FAXE Active Care is a cleaning and wood care agent for oiled and other open pored,

treated surfaces. Active Care contains mild, surfactants (surface-active agents) and

nurturing wax.

Application: It is suitable for use on natural, oiled wooden floors, cork and linoleum, unglazed tiles

and natural stone.

Properties: Active Care dries to give silk mat or mat look. It forms a water-repellent and easy to

clean protective surface.

Solids: 17 weight % 17 vol. %

Pre-treatment: Use a vacuum cleaner to remove loose dirt before starting treatment. Before the first

application, remove any old conditioner and stubborn dirt using Faxe Intensive Cleaner. the surface is in poor condition, first apply a coat f oil and allow this to dry. Do not clean

newly oiled surfaces for the first 7 days after application.

Application:

Method: Recommended viscosity: Thinner:

First application: Lambswool applicator

Cleaning: mop, bucket

Drying:

	Drying time	Film thickness - dry
Dry to use	1 hour 20 °C	-

System Specification:

First application:

NB! Do not use FAXE Active Care White undiluted!

FAXE Active care has to be shaking before use.

- Apply undiluted FAXE Active Care naturel to the clean surface, with the grain. Work wet-on-wet and do not wipe over areas that have already dried.
- · Allow to dry for 60 minutes.
- Protect from water during the first few days after application.

Cleaning: • Add Active Care to the cleaning water: 1 part Active Care to 20 parts of water. Use 1 part Active Care to 10 parts water, if the area is subject to heavy wear or the wood is dark.

- Mop the floor, with the grain, using a wet mop to remove the dirt.
- Allow to dry for 30 -60 minutes.

Aftercare:

As a rule, wood should be cleaned from time to time using Active Care as a cleaning water additive. If necessary, the Active Care film can be removed using Intensive Cleaner.

Coverage:	Theoretical: 50 m²/ltr.	
Storage:	Frostfree, cool, and closed.	
Shelf-life:	12 Months in an unopened container	
Cleaning:	The tools should be cleaned with water.	

Product Name: FAXE Active Care 0280 07300 - 07301

Date of revision: 31. Aug. 2021. Replace: 11. Oct. 2011 Version no.: 12

Note:

Pour the content in a bucket and stir well during use. If several containers containing identical product are to be used, they should be mixed together first in order to ensure a uniform result. It is always recommended to make a small test area to check surface, adhesion and colour tone.

Page 2/2

This information is based on our present state of knowledge and is intended to provide general notes on our products and their use. It should not, therefore, be construed as guaranteeing specific properties of the product described or its suitability for a particular application. The quality of our products is guaranteed under our General Conditions of Sale.

EFApaint A/S, Energivej 13, DK-6700 Esbjerg

TLF. +45 75 12 86 00 e-mail: info@efapaint.dk

www.efapaint.dk